

Flower Trimmer Operating Instruction

1 Remove the top from the flower trimmer's base



Remove the top from the flower trimmer's base. The inside of the top contains the high-density rubber tongues that are used to push the plant leaves into the blade grill. The cutting blades or wires are located below the grill.

2 Place the untrimmed plants on the grill

Place the untrimmed plants on top of the grill. The plants should be many to make sure the grill surface is covered (approximately 40 dry grams).



3 Place the top and handle back on the base



Place the top and handle back on the top of the trimmer's base.

4 Turn the handle clockwise about 15-30 rounds

Using the handle, make 15-30 complete turns. While spinning the handle, the inside rubber twist tongues multiplies the rate of the spinning plants and blades by over 30 times.

A combination of the rubber tongues presses and rolls the plants into the spinning blades can improve the cutting efficiency. Only 30 seconds can yield one hour's work.



5 Remove the top and collect the plants



Open the top and the trimmed plants and their fragmental bud/leaves can be found individually on the middle grill and in the trimmer basin.

Depending on the type of plants, the trimming can be used for the preparation of plants' essential oils.

6 Repeat the process for more harvest

If you think the leaf pieces are not small enough, keep repeating the above process as many times as you want, or until you have completed your harvest. When finished, easy clean every part of the trimmer and store it.



WARNINGS:

- ◆ Never place your fingers, gloves or any other body part in contact with the grill or the blade.
- ◆ Do not use scissors, knives or any instrument above the grill.

Please Note:

The manufacturer does not accept any responsibility for damages caused to or by the trimmers resulting from an inadequate use or assembly. Please use the trimmers in accordance with existing laws and regulations.